







# Ch. 6 Analysis of Structures



- For the equilibrium of structures made of several connected parts, the *internal forces* as well the *external forces* are considered.
- In the interaction between connected parts, Newton's 3<sup>rd</sup> Law states that the *forces of action and reaction* between bodies in contact have the same magnitude, same line of action, and opposite sense.
- Three categories of engineering structures are considered:
  - a) *Trusses*: formed from *two-force members*, i.e., straight members with end point connections and forces that act only at these end points.
  - b) *Frames*: contain at least one multi-force member, i.e., member acted upon by 3 or more forces.
  - c) *Machines*: structures containing moving parts designed to transmit and modify forces.


# Definition of a Truss




- A truss consists of straight members connected at joints. No member is continuous through a joint.
- Most structures are made of several trusses joined together to form a space framework. Each truss carries those loads which act in its plane and may be treated as a two-dimensional structure.
- Bolted or welded connections are assumed to be pinned together. Forces acting at the member ends reduce to a single force and no couple. Only *two-force members* are considered.
- When forces tend to pull the member apart, it is in *tension*. When the forces tend to compress the member, it is in *compression*.

Members of a truss are slender and not capable of supporting large lateral loads. Loads must be applied at the joints.


# Definition of a Truss



Pratt




Howe




Fink


Typical Roof Trusses



Pratt




Howe



Warren




Baltimore




K truss


Typical Bridge Trusses



Stadium






Cantilever portion  
of a truss



Bascule

Other Types of Trusses



# Simple Trusses



- A *rigid truss* will not collapse under the application of a load.


- A *simple truss* is constructed by successively adding two members and one connection to the basic triangular truss.

# Analysis of Trusses by the Method of Joints




- Dismember the truss and create a freebody diagram for each member and pin.
- Conditions for equilibrium for the entire truss can be used to solve for 3 support reactions.
- The two forces exerted on each member are equal, have the same line of action, and opposite sense.
- Forces exerted by a member on the pins or joints at its ends are directed along the member and equal and opposite.
- Conditions of equilibrium are used to solve for 2 unknown forces at each pin (or joint), giving a total of  $2n$  solutions, where  $n$ =number of joints. Forces are found by solving for unknown forces while moving from joint to joint sequentially.

# Joints Under Special Loading Conditions







- Forces in opposite members intersecting in two straight lines at a joint are equal.
- The forces in two opposite members are equal when a load is aligned with a third member. The third member force is equal to the load (including zero load).
- The forces in two members connected at a joint are equal if the members are aligned and zero otherwise.
- Recognition of joints under special loading conditions simplifies a truss analysis.





# Problems 6.31 6.32

Copyright © The McGraw-Hill Companies, Inc. Permission required for reproduction or display.



**For the given loading, determine the zero-force members in each of the two trusses shown.**



# Space Trusses



- An *elementary space truss* consists of 6 members connected at 4 joints to form a tetrahedron.
- A *simple space truss* is formed and can be extended when 3 new members and 1 joint are added at the same time.
- In a simple space truss,  $m = 3n - 6$  where  $m$  is the number of members and  $n$  is the number of joints.
- Conditions of equilibrium for the joints provide  $3n$  equations. For a simple truss,  $3n = m + 6$  and the equations can be solved for  $m$  member forces and 6 support reactions.
- Equilibrium for the entire truss provides 6 additional equations which are not independent of the joint equations.



# Sample Problem 6.1



Using the method of joints, determine the force in each member of the truss.

$$\begin{aligned} \sum M_C &= 0 \\ &= (2000 \text{ lb})(24 \text{ ft}) + (1000 \text{ lb})(12 \text{ ft}) - E(6 \text{ ft}) \end{aligned}$$

$$E = 10,000 \text{ lb } \uparrow$$



$$\sum F_x = 0 = C_x$$

$$C_x = 0$$

$$\sum F_y = 0 = -2000 \text{ lb} - 1000 \text{ lb} + 10,000 \text{ lb} + C_y$$

$$C_y = 7000 \text{ lb } \downarrow$$

# Sample Problem 6.1




- We now solve the problem by moving sequentially from joint to joint and solving the associated FBD for the unknown forces.
- Joints *A* or *C* are equally good because each has only 2 unknown forces.

$$\frac{2000 \text{ lb}}{4} = \frac{F_{AB}}{3} = \frac{F_{AD}}{5}$$

$$F_{AB} = 1500 \text{ lb } T$$

$$F_{AD} = 2500 \text{ lb } C$$



- Joint *D*, since it has 2 unknowns remaining (joint *B* has 3).


$$F_{DB} = F_{DA}$$

$$F_{DE} = 2\left(\frac{3}{5}\right)F_{DA}$$

$$F_{DB} = 2500 \text{ lb } T$$

$$F_{DE} = 3000 \text{ lb } C$$

# Sample Problem 6.1



- There are now only two unknown member forces at joint B. Assume both are in tension.

$$\sum F_y = 0 = -1000 - \frac{4}{5}(2500) - \frac{4}{5}F_{BE}$$

$$F_{BE} = -3750 \text{ lb}$$

$$F_{BE} = 3750 \text{ lb } C$$

$$\sum F_x = 0 = F_{BC} - 1500 - \frac{3}{5}(2500) - \frac{3}{5}(3750)$$

$$F_{BC} = +5250 \text{ lb}$$


$$F_{BC} = 5250 \text{ lb } T$$

- There is one remaining unknown member force at joint E (or C). Use joint E and assume the member is in tension.


$$\sum F_x = 0 = \frac{3}{5}F_{EC} + 3000 + \frac{3}{5}(3750)$$

$$F_{EC} = -8750 \text{ lb}$$

$$F_{EC} = 8750 \text{ lb } C$$




# Sample Problem 6.1




- All member forces and support reactions are known at joint  $C$ . However, the joint equilibrium requirements may be applied to check the results.

$$\sum F_x = -5250 + \frac{3}{5}(8750) = 0 \quad (\text{checks})$$

$$\sum F_y = -7000 + \frac{4}{5}(8750) = 0 \quad (\text{checks})$$



# Problem 6.19



**SOLUTION**

Free body: Truss:



$$\sum F_x = 0: A_x = 0$$

Due to symmetry of truss and loading,

$$A_y = G = \frac{1}{2} \text{ total load} = 6 \text{ kips} \uparrow$$

Free body: Joint A:

$$\frac{F_{AB}}{5} = \frac{F_{AC}}{3} = \frac{6 \text{ kips}}{4}$$




$$F_{AB} = 7.50 \text{ kips } C \leftarrow$$

$$F_{AC} = 4.50 \text{ kips } T \leftarrow$$

Free body: Joint B:

$$\frac{F_{BC}}{5} = \frac{F_{BD}}{6} = \frac{7.5 \text{ kips}}{5}$$




$$F_{BC} = 7.50 \text{ kips } T \leftarrow$$

$$F_{BD} = 9.00 \text{ kips } C \leftarrow$$

**Determine the force in each member of the Warren bridge truss shown. State whether each member is in tension or compression.**

Free body: Joint C:



$$+\uparrow \sum F_y = 0: \frac{4}{5}(7.5) + \frac{4}{5}F_{CD} - 6 = 0$$

$$F_{CD} = 0 \leftarrow$$



$$+\rightarrow \sum F_x = 0: F_{CE} - 4.5 - \frac{3}{5}(7.5) = 0$$

$$+\uparrow F_{CE} = +9 \text{ kips}$$

$$F_{CE} = 9.00 \text{ kips } T \leftarrow$$



Truss and loading is symmetrical about  $\phi$ .

# Analysis of Trusses by the Method of Sections




- When the force in only one member or the forces in a very few members are desired, the *method of sections* works well.
- To **determine the force in member  $BD$** , form a *section* by “cutting” the truss at  $n-n$  and create a free body diagram for the left side.
- An FBD could have been created for the right side, but this is a less desirable choice.
- Notice that the exposed internal forces are all *assumed* to be in tension.
- With only three members cut by the section, the equations for static equilibrium may be applied to determine the unknown member forces, including  $F_{BD}$ .

# Analysis of Trusses by the Method of Sections





- Assume that the initial section cut was made using line  $k-k$ . **Would this be a poor choice?**
- Notice that *any* cut may be chosen, so long as the cut creates a separated section.
- So, for example, this cut with line  $p-p$  is acceptable.

# Sample Problem 5.126




**Locate the centroid of the volume obtained by rotating the shaded area about the  $x$ -axis.**

Copyright © The McGraw-Hill Companies, Inc. Permission required for reproduction or display.






## Sample Problem 6.3



Determine the force in members  $FH$ ,  $GH$ , and  $GI$ .

1. Draw the FBD for the entire truss. Apply the equilibrium conditions and solve for the reactions at  $A$  and  $L$ .
2. Make a cut through members  $FH$ ,  $GH$ , and  $GI$  and take the right-hand section as a free body (the left side would also be good).
3. Apply the conditions for static equilibrium to determine the desired member forces.

## Sample Problem 6.3



### SOLUTION:

- Take the entire truss as a free body. Apply the conditions for static equilibrium to solve for the reactions at A and L.

$$\begin{aligned} \sum M_A = 0 = & -(5\text{ m})(6\text{ kN}) - (10\text{ m})(6\text{ kN}) - (15\text{ m})(6\text{ kN}) \\ & - (20\text{ m})(1\text{ kN}) - (25\text{ m})(1\text{ kN}) + (25\text{ m})L \end{aligned}$$


$$L = 7.5\text{ kN} \uparrow$$

$$\sum F_y = 0 = -20\text{ kN} + L + A_y$$

$$A_y = 12.5\text{ kN} \uparrow$$

$$\sum F_x = 0 = A_x$$

# Sample Problem 6.3



- Make a cut through members  $FH$ ,  $GH$ , and  $GI$  and take the right-hand section as a free body.

- What is the one equilibrium equation that could be solved to find  $F_{GI}$ ?

- Sum of the moments about point H:

$$\sum M_H = 0$$


$$(7.50 \text{ kN})(10 \text{ m}) - (1 \text{ kN})(5 \text{ m}) - F_{GI}(5.33 \text{ m}) = 0$$

$$F_{GI} = +13.13 \text{ kN}$$

$$F_{GI} = 13.13 \text{ kN } T$$

# Sample Problem 6.3

- $F_{FH}$  is shown as its components. What one equilibrium equation will determine  $F_{FH}$ ?



$$\tan \alpha = \frac{FG}{GL} = \frac{8 \text{ m}}{15 \text{ m}} = 0.5333 \quad \alpha = 28.07^\circ$$


$$\sum M_G = 0$$

$$(7.5 \text{ kN})(15 \text{ m}) - (1 \text{ kN})(10 \text{ m}) - (1 \text{ kN})(5 \text{ m}) + (F_{FH} \cos \alpha)(8 \text{ m}) = 0$$

$$F_{FH} = -13.82 \text{ kN}$$

$$F_{FH} = 13.82 \text{ kN } C$$

- There are many options for finding  $F_{GH}$  at this point (e.g.,  $\sum F_x = 0$ ,  $\sum F_y = 0$ ). Here is one more:



$$\tan \beta = \frac{GI}{HI} = \frac{5 \text{ m}}{\frac{2}{3}(8 \text{ m})} = 0.9375 \quad \beta = 43.15^\circ$$




$$\sum M_L = 0$$

$$(1 \text{ kN})(10 \text{ m}) + (1 \text{ kN})(5 \text{ m}) + (F_{GH} \cos \beta)(10 \text{ m}) = 0$$

$$F_{GH} = -1.371 \text{ kN}$$




$$F_{GH} = 1.371 \text{ kN } C$$

# Analysis of Frames




- *Frames* and *machines* are structures with at least one *multiforce* ( $>2$  forces) member. Frames are designed to support loads and are usually stationary. Machines contain moving parts and transmit and modify forces.
- A free body diagram of the complete frame is used to determine the external forces acting on the frame.
- Internal forces are determined by dismembering the frame and creating free-body diagrams for each component.
- Forces on two force members have known lines of action but unknown magnitude and sense.
- Forces on multiforce members have unknown magnitude and line of action. They must be represented with two unknown components.
- Forces between connected components are equal, have the same line of action, and opposite sense.

## Frames Which Cease To Be Rigid When Detached From Their Supports



- Some frames may collapse if removed from their supports. Such frames can not be treated as rigid bodies.
- A free-body diagram of the complete frame indicates four unknown force components which cannot be determined from the three equilibrium conditions (statically indeterminate).
- The frame must be considered as two distinct, but related, rigid bodies.
- With equal and opposite reactions at the contact point between members, the two free-body diagrams show 6 unknown force components.
- Equilibrium requirements for the two rigid bodies yield 6 independent equations. Thus, taking the frame apart made the problem solvable.


## Sample Problem 6.4



1. Create a free body diagram for the complete frame and solve for the support reactions.

Members  $ACE$  and  $BCD$  are connected by a pin at  $C$  and by the link  $DE$ . For the loading shown, determine the force in link  $DE$  and the components of the force exerted at  $C$  on member  $BCD$ .

# Sample Problem 6.4



## SOLUTION:

1. Create a free-body diagram for the complete frame and solve for the support reactions.

$$\sum F_y = 0 = A_y - 480 \text{ N}$$

$$A_y = 480 \text{ N } \uparrow$$

$$\sum M_A = 0 = -(480 \text{ N})(100 \text{ mm}) + B(160 \text{ mm})$$

$$\sum F_x = 0 = B + A_x$$

$$B = 300 \text{ N } \rightarrow$$

$$A_x = -300 \text{ N}$$


$$A_x = 300 \text{ N } \leftarrow$$

Note:

$$\alpha = \tan^{-1} \frac{80}{150} = 28.07^\circ$$







# Sample Problem 6.4



## SOLUTION (cont.):


2. Create a free body diagram for member BCD (since the problem asked for forces on this body).



## Sample Problem 6.4

### SOLUTION (cont.):

3. Using the best FBD for member BCD, what is the one equilibrium equation that can directly find  $F_{DE}$ ?



$$\sum M_C = 0 = (F_{DE} \sin \alpha)(250 \text{ mm}) + (300 \text{ N})(60 \text{ mm}) + (480 \text{ N})(100 \text{ mm})$$

$$F_{DE} = -561 \text{ N}$$

$$F_{DE} = 561 \text{ N } C$$

- Sum of forces in the  $x$  and  $y$  directions may be used to find the force components at  $C$ .

$$\sum F_x = 0 = C_x - F_{DE} \cos \alpha + 300 \text{ N}$$

$$0 = C_x - (-561 \text{ N}) \cos \alpha + 300 \text{ N}$$


$$C_x = -795 \text{ N}$$

$$\sum F_y = 0 = C_y - F_{DE} \sin \alpha - 480 \text{ N}$$

$$0 = C_y - (-561 \text{ N}) \sin \alpha - 480 \text{ N}$$

$$C_y = 216 \text{ N}$$

# Sample Problem 6.4




- With member  $ACE$  as a free body with no additional unknown forces, check the solution by summing moments about  $A$ .

$$\begin{aligned}\sum M_A &= (F_{DE} \cos \alpha)(300 \text{ mm}) + (F_{DE} \sin \alpha)(100 \text{ mm}) - C_x(220 \text{ mm}) \\ &= (-561 \cos \alpha)(300 \text{ mm}) + (-561 \sin \alpha)(100 \text{ mm}) - (-795)(220 \text{ mm}) = 0\end{aligned}$$


(checks)

# Prob. 6.78



**Determine the components of all forces acting on member ABD of the frame shown.**


## Prob. 6.79




**For the frame and loading shown, determine the components of all forces acting on member ABC.**

# Problems 6.32

# 6.21



**For the given loading, determine the zero-force members in the truss shown.**



**Determine the force in each member of the Pratt bridge truss shown. State whether each member is in tension or compression.**